


Your battery system is required to be in remote mode to be managed by our Social Hub.

To check which mode your battery system is in, look towards to top right hand corner on the side and you should be able to locate 3 silver circular buttons labelled "Remote" "Local" & "Power" in that order.



Two of the 3 buttons should have an illuminated halo one of which will be the Power button and then either Remote or Local will be illuminated, indicating which mode the battery system is in.

If Local is illuminated as shown below ↓ the system will need switching to Remote mode.



To switch the system into remote mode press and hold the remote button until the illumination on the local button goes out this generally takes 6 seconds, now when you release the remote button it should be illuminated as shown below ↓



Your System should now be in the correct mode. Thank you.